
Operating Instructions

SPA-1390 Gooseneck Spa Shower



The SPA-1390 features 2 spray modes and 3 diverter modes.

To experience both spray modes, spray and rain shower, through the overhead and hand shower, turn the shower head or hand shower clockwise or counter clockwise to alternate spray modes.

To select diverter mode rotate diverter knob as follows:

- Left = Overhead Shower Only
- Right = Hand Shower Only
- Center = Over head and hand shower

